


**MODEL: IG10600047C-1224N**



OWNER'S MANUAL

# Tranquil Grove 12'x24' Cedar Framed Hardtop Pavilion


**TABLE OF CONTENTS**


**ASSEMBLY GUIDE**.....02  
**USING YOUR PRODUCT**.....05

August 29, 2025

**QUESTIONS?**





































 **E-mail:** [support@modernshade.org](mailto:support@modernshade.org)

























 **Toll Free Number:** 1-888-666-3070

 **Mon-Fri:** 9:00 AM - 5:00 PM PST.



























# ASSEMBLY GUIDE

## PARTS LIST

<b>A1</b> Post 1 (4pieces) 	<b>A2</b> Post 2 (2pieces) 	<b>B1</b> Foot Base 1 (6pieces) 	<b>C1</b> Foot Cover 1 (6pieces) 	<b>D3</b> Cross Beam 3 (2pieces) 	<b>D4</b> Cross Beam 4 (2pieces) 
P0010000701	P0010000801	P0030000301	P0020000301	P0040016101	P0040016201
<b>D15</b> Cross Beam 15 (2pieces) 	<b>D16</b> Cross Beam 16 (2pieces) 	<b>D17</b> Cross Beam 17 (2pieces) 	<b>D18</b> Cross Beam 18 (2pieces) 	<b>E1</b> Support Bracket 1 (6pieces) 	<b>E2</b> Support Bracket 2 (6pieces) 
P0040019801	P0040019901	P0040020001	P0040020101	P0050000501	P0050000601
<b>F4</b> Roof Rib 4 (4pieces) 	<b>F5</b> Roof Rib 5 (4pieces) 	<b>G4</b> Middle Cross Beam 4 (12pieces) 	<b>G5</b> Middle Cross Beam 5 (4pieces) 	<b>G6</b> Middle Cross Beam 6 (4pieces) 	<b>H1</b> Roof Support 1 (16pieces) 
P0070000501	P0070000601	P0080000501	P0080000801	P0080000901	P0090014801
<b>H2</b> Roof Support 2 (8pieces) 	<b>H3</b> Roof Support 3 (16pieces) 	<b>H8</b> Roof Support 8 (8pieces) 	<b>J1</b> Roof Border 1 (4pieces) 	<b>J2</b> Roof Border 2 (4pieces) 	<b>J3</b> Roof Border 3 (16pieces) 
P0090000202	P0090014901	P0090002201	P0090015001	P0090015101	P0090015201
<b>K1</b> Connector 1 (20pieces) 	<b>K2</b> Connector 2 (4pieces) 	<b>K3</b> Connector 3 (60pieces) 	<b>K4</b> Connector 4 (12pieces) 	<b>K5</b> Connector 5 (6pieces) 	<b>K6</b> Connector 6 (4pieces) 
P0060001501	P0060001701	P0060000501	P0060000602	P0110005301	P0060005001
<b>K7</b> Connector 7 (20pieces) 	<b>K8</b> Connector 8 (2pieces) 	<b>K11</b> Connector 11 (6pieces) 	<b>K21</b> Connector 21 (2pieces) 	<b>K22</b> Connector 22 (1piece) 	<b>K26</b> Connector 26 (2pieces) 
P0110000502	P0060008301	P0110005401	P0060008101	P0060008201	P0060011901

<p><b>L9</b> Roof Rib Cover 9 (4pieces)</p> 	<p><b>L10</b> Roof Rib Cover 10 (4pieces)</p> 	<p><b>L11</b> Roof Cover 11 (1piece)</p> 	<p><b>L12</b> Roof Cover 12 (1piece)</p> 	<p><b>M1</b> Mosquito Net Rod 1 (2pieces)</p> 	<p><b>M2</b> Mosquito Net Rod 2 (2pieces)</p> 
P0120001001	P0120001101	P0120004301	P0120004401	P0100002801	P0100002901
<p><b>M3</b> Mosquito Net Rod 3 (2pieces)</p> 	<p><b>M4</b> Mosquito Net Rod 4 (2pieces)</p> 	<p><b>M5</b> Mosquito Net Rod 5 (4pieces)</p> 	<p><b>N</b> Hook (1piece)</p> 	<p><b>P3</b> Middle Cross Beam Support 3 (6pieces)</p> 	<p><b>Z4</b> Roof Plate 4 (4pieces)</p> 
P0100001601	P0100001701	P0100003001	P1000000100	P0050006801	P0130000499
<p><b>Z5</b> Roof Plate 5 (4pieces)</p> 	<p><b>Z6</b> Roof Plate 6 (4pieces)</p> 	<p><b>Z7</b> Roof Plate 7 (4pieces)</p> 	<p><b>Z15</b> Roof Plate 15 (2pieces)</p> 	<p><b>Z16</b> Roof Plate 16 (2pieces)</p> 	<p><b>Z17</b> Roof Plate 17 (2pieces)</p> 
P0130000599	P0130000699	P0130000799	P0130001599	P0130001699	P0130001799
<p><b>Z18</b> Roof Plate 18 (10pieces)</p> 	<p><b>Z19</b> Roof Plate 19 (16pieces)</p> 	<p><b>Z48</b> Roof Plate 48 (4pieces)</p> 	<p><b>Z49</b> Roof Plate 49 (4pieces)</p> 	<p><b>Z50</b> Roof Plate 50 (4pieces)</p> 	<p><b>Z51</b> Roof Plate 51 (4pieces)</p> 
P0130001899	P0130001999	P0130007099	P0130007199	P0130007299	P0130007399

## HARDWARE

<b>AA</b> Bolt M5*25 (196+10 pieces) 	<b>BB</b> Bolt M8*35 (48+2 pieces) 	<b>CC</b> Bolt M10*65 (10+1 pieces) 	<b>DD</b> Bolt M6*20 (294+16 pieces) 	<b>EE</b> Bolt M6*45 (24+2 pieces) 	<b>FF</b> Bolt M8*45 (36+2 pieces) 
H0008008098	H0008008099	H0008008100	H0008008036	H0008008016	H0008008191
<b>GG</b> Bolt M10*160 (10+1 pieces) 	<b>HH</b> Anti-slip Screw Nut M10 (10+1 pieces) 	<b>JJ</b> M8 Ball nut (36+2 pieces) 	<b>KK</b> M6 Flat washer (458+25 pieces) 	<b>LL</b> M8 Flat washer (120+6 pieces) 	<b>MM</b> M10 Flat washer (30+2 pieces) 
H0008008140	H0008008126	H0008008192	H0008008057	H0008008058	H0008008141
<b>NN</b> M6 Sealant Washer (16+2 pieces) 	<b>PP</b> Double Open End Wrench M8/M10 (2 pieces) 	<b>RR</b> M6 Allen Key (2 pieces) 	<b>SS</b> M8 Allen Key (2 pieces) 	<b>TT</b> Double Open End wrench M5/M6 (2 pieces) 	<b>VV</b> Bolt M6*15 (140+7 pieces) 
H0008008060	H0008008190	H0008008133	H0008008129	H0008008121	H0008008001
<b>XX</b> Concrete Anchor M6*60 (12 pieces) 	<b>YY</b> M5x14 Double head screw (20+1 pieces) 	<b>ZZ</b> M5 Ball nut (20+1 pieces) 	<b>ZY</b> M5 Flat washer (36+2 pieces) 	<b>ZX</b> M5 Sealant washer (36+2 pieces) 	<b>ZV</b> Bolt M5*25 (16+1 pieces) 
H0008008095	H0008008163	H0008008164	H0008008056	H0008008059	H0008008138
<b>ZU</b> M6 Hex drill bit (1 piece) 	<b>ZT</b> M8 Hex drill bit (1 piece) 				
H0008008209	H0008008210				

### IMPORTANT:

This instruction manual contains important information necessary for the proper assembly and safe use of the product.

Read and follow all warnings and instructions before assembling and using the product.

Follow all warnings and instructions when using the product.

Keep this manual for future reference.

Installer/Assembler: leave these instructions with the consumer.

### SAFETY ALERT KEY

#### DANGER

Indicates a hazardous situation that, if not avoided, will result in death or serious injury.

#### WARNING

Indicates a hazardous situation that, if not avoided, could result in death or serious injury.

#### CAUTION

Indicates a hazardous situation that, if not avoided, could result in minor or moderate injury.

#### NOTICE

Indicates information considered important, but not hazard-related (e.g. messages related to property damage).

# ASSEMBLY INSTRUCTIONS


- Please carefully unpack each of the components and hardware. check the components against the parts list and make sure there are no missing parts. lay pieces on cardboard or a soft mat to help protect the pieces from scratches.

## ⚠ CAUTION

Watch for sharp edges when handling the pieces, wear gloves to avoid injury.

### STEP 01


Slide foot base **B1** and foot cover **C1** onto post **A1** . Use four (4) **[AA]** bolts to attach foot base **B1** to post **A1** . Repeat with the other three (3) posts **A1** and two (2) posts **A2** .



- For ease of assembly, it is recommended to have 3 or more people and allow enough time to completely finish the assembly. assembly can take 6-8 hours. a step-ladder is required for assembly (not included).
- Follow step by step instructions, and follow all safety warnings provided with your tools.
- DO NOT tighten screws until all the screws and washers are properly installed. Tighten screws securely, do not over tighten.
- Gazebo should not be used in inclement weather and high winds.

### STEP 02

Attach cross beam **D3** and **D4** together using connector **K5** and **K11** .Secure with six (6) **[FF]** bolts,twelve (12 ) **[LL]** flat washers and six (6) **[JJ]** ball nuts on the sides. Use six (6) **[AA]** bolts secure both the top and bottom of the connection. Repeat to make a second assembly.





**STEP 03**

Attach cross beam **D15** and **D17** together using connector **K5** and **K11**. Secure with six (6) **[FF]** bolts, twelve (12) **[LL]** flat washers and six (6) **[JJ]** ball nuts on the sides. Use six (6) **[AA]** bolts secure both the top and bottom of the connection. Repeat to make a second assembly.

Repeat to make another two assemblies with cross beam **D16** and **D18**.


- [AA]** x 24
- [FF]** x 24
- [JJ]** x 24
- [LL]** x 48



**STEP 04**

Attach the cross beam assembly **D3 D4** to left **A1** post using one (1) **[CC]** bolt and **[MM]** washer in the top hole, and one (1) **[GG]** bolt, two (2) **[MM]** washers, and one (1) **[HH]** nut in the bottom hole. Attach the cross beam assembly to right **A1** post, using one (1) **[GG]** bolt, two (2) **[MM]** washers, and one (1) **[HH]** nut in the top hole, and one (1) **[CC]** bolt and **[MM]** washer in the bottom hole. Repeat to make a second assembly.


- [CC]** x4
- [MM]** x12
- [HH]** x4
- [GG]** x4




**STEP 05**

Attach the cross beam assembly **D15 D17** to left **A1** post using one (1) **[CC]** bolt and **[MM]** washer in the top hole, and one (1) **[GG]** bolt, two (2) **[MM]** washers, and one (1) **[HH]** nut in the bottom hole. Attach the cross beam assembly to **A2** post with connector **K8** and one end of cross beam **D18**, using one (1) **[CC]** bolt and **[MM]** washer in the top hole, and one (1) **[GG]** bolt, two (2) **[MM]** washers, and one (1) **[HH]** nut in the bottom hole.

Attach the cross beam assembly **D18 D16** to right **A1** post using one (1) **[GG]** bolt, two (2) **[MM]** washers, and one (1) **[HH]** nut in the top hole, and one (1) **[CC]** bolt and **[MM]** washer in the bottom hole. Repeat with the other assembly set.



**STEP 06 CRITICAL: SQUARE UNIT BEFORE PROCEEDING TO NEXT STEPS. ONCE SQUARE, TIGHTEN ALL HARDWARE.**




**STEP 07**

Use four (4) **[BB]** bolts and four (4) **[LL]** flat washers to attach one (1) support bracket **E1** to cross beam and post on left corner of each side. Repeat with the other five (5) support brackets **E1**.

Use four (4) **[BB]** bolts and four (4) **[LL]** flat washers to attach one (1) support bracket **E2** to cross beam and post on right corner of each side. Repeat with the other five (5) support brackets **E2**.


**[BB]** x48

**[LL]** x48

**STEP 08**

Use eight (8) **[AA]** bolts to attach one (1) connector **K2** to each corner.

**[AA]** x32




**STEP 09**

Slide roof rib **F4** onto **F5**. Securing with two (2) **[VV]** bolts and two (2) **[KK]** flat washers. Use one (1) **[DD]** bolt and one (1) **[KK]** flat washer to attach each connector **K4** to roof rib **F4** **F5**. Repeat with the other two (2) **K4** on one roof rib assembly. Repeat with the other three (3) roof rib assembly.

- [DD]** x12
- [KK]** x20
- [VV]** x8


Make sure the connectors face upward as shown.



**STEP 10**


Slide two (2) connector **K21** onto connector **K22**, then attach hook **N** to the assembly. Secure with twelve (12) **[DD]** bolts and twelve (12) **[KK]** flat washers on the sides, and six (6) **[DD]** bolts and six (6) **[KK]** flat washers on the bottom.

- [DD]** x18
- [KK]** x18



**STEP 11**

Use four (4) [DD] bolts and four (4) [KK] flat washers to attach connector **K21** to roof ribs **F4**. Use two (2) [DD] bolts and two (2) [KK] flat washers to attach each roof rib **F5** to connector **K2** on the posts.




**STEP 12**

Use one (1) [VV] bolt, one (1) [DD] bolt and two (2) [KK] flat washers to attach one (1) mosquito net rod **M1** to connector **K6** and connector **K2** with roof rib **F5**. Repeat with the other **M1** and two (2) **M2**.

Use one (1) [VV] bolt, one (1) [DD] bolt and two (2) [KK] flat washers to attach one (1) mosquito net rod **M4** to connector **K26** on the cross beams and connector **K2** with roof rib **F5**. Repeat with the other **M4** and two (2) **M3**.


Use two (2) [VV] bolts and two (2) [KK] flat washers to attach one (1) mosquito net rod **M5** to connector **K8** and **K6** on the cross beams. Repeat with the other three (3) **M5**.

- [KK] x24
- [DD] x8
- [VV] x16



**STEP 13**

Use four (4) [AA] bolts to attach each connector **K26** to cross beams **D3** **D4** . Repeat with the other **K26** .  
 Use four (4) [AA] bolts to attach each connector **K6** to cross beams **D15** **D16** . Repeat with the other three (3) **K6** .




**STEP 14**

Use two (2) [DD] bolts and two (2) [KK] flat washers to attach one (1) connector **K1** to roof rib **G4** . Repeat with the other eleven (11) **G4** and **K1** .


[KK] x24

[DD] x24



**STEP 15**

Attach connector **K1** on roof rib **G4** to cross beams. Use one (1) **[DD]** bolt and one (1) **[KK]** flat washer to attach the upper end of roof rib **G4** to connector **K21**. Repeat with the other eleven (11) **G4**.




**STEP 16**

Use two (2) **[DD]** bolts and two (2) **[KK]** flat washers to attach one (1) connector **K1** to middle cross beam **G5**. Repeat to make the other three (3) assemblies.


Use two (2) **[DD]** bolts and two (2) **[KK]** flat washers to attach one (1) connector **K1** to middle cross beam **G6**. Repeat to make the other three (3) assemblies.

- [KK]** x16
- [DD]** x16




**STEP 17**

Attach connector **K1** to cross beams. Use one (1) **[VV]** bolt and one (1) **[KK]** flat washer to attach the upper end of **G5** to roof rib **F4**. Repeat with the other three (3) **G5** and four (4) **G6**.



**STEP 18**

Create a roof support assembly by sliding the parts together in this order: **K3**, **H1**, **K3**, **H1**, **K3**, **H1**, **K3**, **H1**, **K3**, **H1**, **K3**, **H1**, **K3**, **H1** and **K3**. Secure using **[VV]** bolts and **[KK]** washers. Repeat the process to make a second assembly.




**STEP 19**

Create a roof support assembly by sliding the parts together in this order: **K3** , **H1** and **K3** . Secure using **[VV]** bolt and **[KK]** washer. Repeat the process to make a second assembly. Repeat the process to make a second assembly.

**[KK]** x4

**[VV]** x4




**STEP 20**

Use two (2) **[YY]** double-headed screws to attach one (1) short roof support assembly **H1 K3** to middle cross beam **G5 / G6** . Repeat with the other roof support assembly **H1 K3** .

Use eight (8) **[YY]** double-headed screws to attach one (1) long roof support assembly **H1 K3** to middle cross beam **G4 / G5 / G6** .


Repeat with the other roof support assembly **H1 K3** .

**[YY]** x20



**STEP 21**


Create a roof support assembly by sliding the parts together in this order: **K3**, **H3**, **K3**, **H3**, **K3**, **H3**, **K3**, **H3**, **K3**, **H3**, **K3**, **H3**, **K3**, **H3** and **K3**. Secure using **[VV]** bolts and **[KK]** washers. Repeat the process to make a second assembly.



**STEP 22**

Create a roof support assembly by sliding the parts together in this order: **K3**, **H3** and **K3**. Secure using **[VV]** bolt and **[KK]** washer. Repeat the process to make a second assembly.

[KK] x4  
[VV] x4



**STEP 23**

Use one (1) [DD] bolt and one (1) [KK] flat washer to attach one (1) short roof support assembly H3 K3 to middle cross beam G5 / G6 .


Repeat with the other roof support assembly H3 K3 .

Use eight (8) [DD] bolts and eight (8) [KK] flat washers to attach one (1) long roof support assembly H3 K3 to middle cross beam G4 / G5 / G6 .

Repeat with the other roof support assembly H3 K3 .

[KK] x20

[DD] x20




**STEP 24**

Slide roof support H8 onto middle cross beam G5 / G6 . Use two (2) [VV] bolts and two (2) [KK] flat washers to attach one (1) H8 to G5 / G6 and roof rib assembly F4 F5 . Repeat with the other seven (7) H8 .

Slide roof support H2 onto middle cross beam G5 / G6 . Use two (2) [VV] bolts and two (2) [KK] flat washers to attach one (1) H2 to G5 / G6 and roof rib assembly F4 F5 . Repeat with the other seven (7) H2 .


[KK] x32

[VV] x32




**STEP 25**

Create a roof border assembly by sliding the parts together in this order: **K3**, **J3**, **K3**, **J3**, **K3**, **J3**, **K3**, **J3**, **K3**, **J3**, **K3**, **J3**, **K3**, **J3**, **K3**, **J3** and **K3**. Repeat the process to make a second assembly.



**STEP 26**

Create a roof border assembly by sliding the parts together in this order: **K3**, **J3** and **K3**. Repeat the process to make a second assembly



**STEP 27**

Use one (1) [DD] bolt and one (1) [KK] flat washer to attach one (1) short roof border assembly J3 K3 to middle cross beam G5 / G6 .


Repeat with the other roof support assembly J3 K3 .

Use eight (8) [DD] bolts and eight (8) [KK] flat washers to attach one (1) long roof border assembly J3 K3 to middle cross beam G4 / G5 / G6 .

Repeat with the other roof support assembly J3 K3 .

[KK] x20

[DD] x20




**STEP 28**

Slide roof border J1 onto G5 / G6 . Use one (1) [DD] and one (1) [KK] flat washer to attach J1 to roof rib F4 F5 .

Repeat with the other three (3) J1 and four (4) J2 .

[KK] x8

[DD] x8




**STEP 29**

Use two (2) [DD] bolts and two (2) [KK] flat washers to attach one (1) connector **K7** to roof borders. Repeat with the other nineteen (19) connectors **K7**.

[KK] x40


[DD] x40



**STEP 30**

Use four (4) [AA] bolts to attach each connector **K1** to cross beams.

[AA] x80




**STEP 31**

Use two (2) [VV] bolts and two (2) [KK] flat washers to attach one (1) middle cross beam support P3 to middle cross beam G4. Repeat with the other five (5) P3.

[KK] x12

[VV] x12

**STEP 32**


DO NOT tighten the bolts completely until all the bolts and washers are properly installed.

Overlap the edges of the adjacent roof plates together.

Use one (1) [DD] bolt and one (1) [KK] flat washer to attach each hole of roof plates Z19 to the frame.

[KK] x32

[DD] x32




**STEP 33**

Overlap the edges of the adjacent roof plates together.

Use one (1) [ZZ] ball nut, one (1) [ZX] sealant washer and one (1) [ZY] flat washer to attach each hole in the black circle of roof plates **Z18** to the [YY] screw.

Use one (1) [ZV] bolt, one (1) [ZX] sealant washer and one (1) [ZY] flat washer to attach each hole in the red circle of roof plates **Z18** to the frame.

- [ZZ] x8
- [ZX] x18
- [ZY] x18
- [ZV] x10



**STEP 34**


Overlap the edges of the adjacent roof plates together.

Use one (1) [DD] bolt and one (1) [KK] flat washer to attach each hole on the roof plates **Z15**, **Z16** and **Z17** to the frame.

Use one (1) [ZZ] ball nut, one (1) [ZX] sealant washer and one (1) [ZY] flat washer to attach each hole in the red circle of lower end of roof plates **Z16** and **Z17** to the [YY] screw.


Use one (1) [ZV] bolt, one (1) [ZX] sealant washer and one (1) [ZY] flat washer to attach each hole in the black circle of roof plates **Z15**, **Z16** and **Z17** to the frame.

- [ZZ] x4    [ZV] x6
- [ZX] x10   [DD] x8
- [ZY] x10   [KK] x8




**STEP 35**

Slide roof cover **L11** to **L12**. Use one (8) **[EE]** bolt and eight (8) **[KK]** flat washer to attach roof cover **L11** **L12** to connector **K21**.



**STEP 36**


Overlap the edges of the adjacent roof plates together. Use one (1) **[DD]** bolt and one (1) **[KK]** flat washer to attach each hole of roof plates **Z48** and **Z49** to the frame.



**STEP 37**

Use one (1) [DD] bolt and one (1) [KK] flat washer to attach each hole on the roof plates **Z50** and **Z51** to the frame.  
 Use one (1) [ZZ] ball nut, one (1) [ZX] sealant washer and one (1) [ZY] flat washer to attach each hole in the black circle of lower end of roof plates **Z50** and **Z51** to the [YY] screw.


- [ZZ] x8
- [ZX] x8
- [ZY] x8
- [DD] x8
- [KK] x8



**STEP 38**

Use two (2) [EE] bolts, two (2) [KK] flat washers and two (2) [NN] flat washers to attach one (1) roof rib cover **L9** to the roof. Repeat with the other three (3) roof rib covers **L9**.

- [EE] x8
- [KK] x8
- [NN] x8




**STEP 39**

Use one (1) **[DD]** bolt and one (1) **[KK]** flat washer to attach each top hole of roof plates **Z4** , **Z5** , **Z6** and **Z7** to the frame.

**[DD]** x32

**[KK]** x32




**STEP 40**

Slide roof rib cover **L10** into **L9** . Use two (2) **[EE]**, two (2) **[KK]** flat washers and two (2) **[NN]** flat washers to attach one (1) roof rib cover **L10** to the roof. Repeat with the other three (3) roof rib covers **L10** .

**[EE]** x8

**[KK]** x8


**[NN]** x8



**STEP 41**


Use two (2) **[XX]** expansion bolts to anchor each post foot base **B1**. please make sure the expansion bolts are fully anchored. We recommend using a 3/8 inch drill bit when installing the included expansion bolts.

**[XX]** x12



Outdoor Structure anchoring guide for anchoring gazebo to wood or concrete: If step 41, on page 25 in the assembly instructions is not properly completed, this will void the warranty.

**WARNING!** If your gazebo is not properly anchored, damage could occur. It is highly recommended for maximum safety that you mount and secure to wood or concrete footers. This is far better and safer than using ground stakes. The following are some examples of how to mount the structure to wood or concrete surfaces. Refer to local building codes or consider consulting a licensed contractor for assistance in the anchoring of this product.



If digging for foundation, please double check for possibility of any underground utilities such as gas, telephone, cable or sprinkler lines. Refer to your local building and city codes, ordinances, neighborhood covenants, or height restrictions regarding this type of structure for guidance on acceptable installation requirements.

**CAUTION**

DO NOT climb or walk on roof for any reason.

- Our components are intended for privacy, decorative and ornamental use only.
- Product is NOT INTENDED for the following:
  - A safety barrier to prevent unsupervised access to pools, hot tubs, spas or ponds.
  - As load bearing support for a building, structure, heavy objects or swings.
  - Used in structures that trap wind, rain or snow that would create extra load on the product.
  - Accumulated snow must be removed from roof.
  - DO NOT climb or walk on roof for any reason.

### LIMITED WARRANTY

We warrants this product against defects in materials and workmanship for a period of one (1) year from the original date of purchase. To the extent any such defects occur, our products will send the appropriate replacement part(s) at no charge.

This warranty does not cover:

- Inspection costs or labor for replacement of any defective parts);
- Incidental or consequential damages;
- Cosmetic defects which DO NOT affect performance;
- Normal wear and tear;
- Damage due to vandalism; acts of nature, including but not limited to wind, storms, hail, floods;
- Improper assembly, installation, or use;
- Discoloration or fading of the finish as a result of exposure to chemicals, spills, pool or salt water
- Corrosion/ rust.

Your product has been designed for safety and quality.

Any modifications made to the original product could compromise its structural integrity or function, and could lead to product failure or personal injury. As such, modifying this product voids any and all warranties.

This product is warranted for RESIDENTIAL USE ONLY, and is not for commercial, contract or other non-residential purposes. Products disclaims all other representations and warranties of any kind, express or implied.

The warranty applies to the original purchaser and is non-transferable. It does not apply to purchases of display models, or when the product is sold on clearance or "as is".

We makes no warranty whatsoever in respect to accessories or parts not supplied with it. This warranty shall apply only within the boundaries of the United States of America and Canada. This warranty gives the original purchaser specific rights, and the original purchaser may also have other rights, which vary from state to state.

